

Green Sleep®

## Your GreenSleep foundation(s) are ready to accept your GreenSleep mattress

- For standard "Metal Bed Frames" Simply place your foundation(s) inside the metal frame
- For platform bed frames – You need horizontal support slats approximately 2-3" apart for proper support and to allow air circulation for the mattress
- For Greensleep foundation(s) ordered with wooden legs follow the instructions #1 "Install the Legs."



### 1 Install the Legs

- Turn each Euro Dowel Base foundation(s) up side down.
- Unwrap all cylindrical wooden legs.
- Each individual twin, full and king foundation requires 4 legs. Queen foundations have 6 legs which include 2 additional legs for center support.
- Place the threaded end of the leg into the threaded leg holes and very gently, turn the leg counter clockwise until tightened. If the leg does not turn smoothly, start again to avoid stripping the threads.
- Screw in all the legs.




### 2 Put your Foundation(s) in Place

- Turn your foundation over so that it is standing on its legs.
- For King size beds, both foundations must be together so that there is no space where they meet in the middle.
- Now you are ready to put your mattress together.



### 3 Put your Mattress Cover in Place

- Unzip your mattress cover and place the velour side on top of the foundation.
- The mattress cover should be placed squarely on top of the foundation. Place the GreenSleep logo at the foot of the bed.



### 4 Insert the Bottom 2" Firm Pad(s)

- Your 2" firm bottom pad(s) will have a tag labeled "firm"
- Place the 2" firm rubber pad(s) squarely inside the bottom of the cover; align all the corners. The rubber pad may appear larger than the cover but will compress into the cover properly when it has been zipped close.
- For Queen and King mattresses, place the rubber pads tightly next to each other with no space in between them.

INSTALLATION



## Insert the 4" Middle Pad(s)

- Place the 4" comfort pad(s) directly on top of the 2" firm pad(s).
- If your mattress is King or Queen size you may have ordered your 4" core pads in different firmnesses. Be sure you place the correct firmness on the proper side of the bed by checking the tag label.



## Insert the 2" Soft Top Pad

- Place the 2" soft pad on top of the 4" middle pads.
- Align the corners so all three layers are square. You are now ready to close the mattress cover.



## Closing the Cover

- Pull the top of the cover over the three layers of rubber.
- The cover is knit and will stretch into place. Before closing the zipper it is important to pull the top and bottom of the cover together so the zipper is aligned in the center of the side border.



## Before Closing the Zipper

- Push the rubber inside the cover so there is little or no pressure on the zipper teeth. This will allow you to align the top and bottom cover so the zipper falls in the center of the border.



## Closing the Zipper

- As you pull the zipper tab around, continue to push in the rubber and align the zipper by pulling the top and bottom of the cover together.
- Once completed square your mattress to the foundation

**Have a good night's sleep!**